



B181A
Low torque switch
(SPDT) on-on
250V 3A




B182G (B1950)
Reed-alarm switch push on type
Operating gap 3.5mm Max.




B181L
Pushbutton switch
(SPDT) on-on
250V 5A

Color:red yellow green
blue orange white




B182H (B1951)
Reed-alarm switch NC type
Operating gap 2cm Max.




B181M
Illuminated pushbutton
switch W/O lamp
(SPDT) on-on
12V 1A

Color:red yellow
green blue




B182J (B1952)
Reed-alarm switch NC type
Operating gap 2.3cm Max.




B181N
Illuminated pushbutton
switch W/O lamp
(SPDT) on-on
12V 1A

Color:red yellow
green blue




B182K (B1953)
Reed-alarm switch NO and NC Type

B182M (B1954)
Reed-alarm switch NC type




B181P
Illuminated pushbutton
switch W/O lamp
(SPDT) on-on
12V 1A

Color:red yellow green
blue white pink




B182N (B1955)
Reed-alarm switch NO type
Operating gap 3cm Max.





B181Q
Illuminated pushbutton
switch W/O lamp
(SPDT) on-on
12V 1A


Color:red yellow green
blue white pink




B182C
Omnipotent joystick
on-off
12V 1A



B182R (B1957)
Reed-alarm switch NC type
Dust proof
Operating gap 4cm Max.



B182D
Omnipotent joystick
on-off
12V 1A



B182S (B1958)
Reed-alarm switch NC type
Double-deck shell to conceal
Screw hold
Operating gap 3.2cm Max.

